

Tetherball

PARK & SUN SPORTS®

Instructions



ADULT ASSEMBLY AND SUPERVISION REQUIRED
 Inspect equipment before each use making sure all hardware, pole sections and ball are secure.
 Park & Sun Sports assumes no liability for misuse of product.

To insure proper set-up, please follow these instructions.

Sleeve Installation

1. Make a hole 8"-10" in diameter and 12" deep.
2. Put duct tape or any heavy duty tape over one end of the PVC sleeve. Fill hole with concrete following manufacturer's instructions.
3. Push the taped end of the PVC sleeve into the concrete and center the sleeve. Make sure concrete does not enter the sleeve. The top of the ground sleeve should be level with the surface of the concrete.
4. Place a weighted object on top of the sleeve to keep it from raising out of the concrete.

Allow the concrete to dry per manufacturer's instructions.

Pole Instructions

1. Connect the pole sections.
2. Attach ball connector to pole eyebolt.
 Make sure safety lock is secure.
3. Ball should hang 24" above the playing surface when installed.

GALVANIZED STEEL POLE

18 gauge steel - Heavy duty construction
 Weather resistant
 Assembles to standard playing height

SYNTHETIC BALL

Soft Touch synthetic cover, machine-stitched
 10mm nylon tether and safety lock connector

HARDWARE

Zinc-plated eyebolt and ball connector
 Offers easy ball attachment and removal

WARNING: Inspect equipment before each use.
 Make sure all hardware, poles and ball are secure.

ACCESSORIES

Ball pump
 12" PVC ground sleeve

